- 1. Carefully remove the scooter from the box
- 2. On the base of the handlebar, remove the hinge pin bolt, put the handle bar in-place, and then re-insert the hinge pin back in place.
- 3. Before using your scooter, loosen the big bolt from the folding mechanism and then use one hand place the mechanism cap and tighten the bolt to secure the handle pole.



4. Insert and secure the left and right handlebars by pressing the spring-loaded bottons and inserting them into the tube.Make Certain the spring-loaded botton engages the hole in the bar each handlebar.



5. Extend seat tube to the full upright position and apply firm pressure to slide it into extend tube from the rear plastic cover. Securely locking the seat tube quick release.



6. Make sure the fuse inside the socket.



If you are in need of additional assistance, visit www.x-tremescooters.com/support/